


# Enabling and Disabling “park” mode on Model 200 door operators.

top right of circuit board



Enabling “park” mode allows the door to be stopped indefinitely in the open position by pushing the remote control a second time after the door opens. Close the door by pushing the button a third time.

jumper  
position

Slide blue  
jumper over  
pair of pins  
as shown